

Assembly instructions for Custom bed

Kit consists of

- Two ends with legs affixed
- Two side rails
- Centre beam (on doubles)
- Optional headboard + 6 screws
- Roll of slats + 10 screws
- Eight nuts, bolts and washers
- Spanner

1) If ordered but not attached, line up the optional headboard's struts in the manner shown and screw through the pre drilled holes.

2) Bolt a side rail to one of the legs. (The arrow on the side rail should point upwards). Tap home gently. Bolt the second rail to the other leg. Repeat at the opposite end.

5) Slot in the centre support beam (on doubles only)

6) Unroll the slats and screw down through the pre-drilled holes.

Any problems please call 020 7739 3480

